







Thank you for purchasing your new Simplicity cold frame. We recommend you familiarise yourself with the instructions and read all safety information before you commence assembly. This instruction manual will also be available online at www.greenhousepeople.co.uk in our technical help section should you need to reprint it. Should you require any additional advice you can always call us on 01782 388811.

Safety Warning

- Glass and aluminium can potentially cause injury. Please ensure you wear protective goggles, gloves, headgear and suitable footwear when assembling and glazing the building.
- Please remember that glass is fragile and should be handled with extreme care. Always clear up and dispose of any breakages immediately.
- In windy conditions please make sure that your cold frame is anchored down properly and that the vents are closed to minimise the chances of damage!

Additional Considerations



- You will find it helpful to prepare a large, clean and clear area in which to work in. A garage floor or flat lawn area is ideal.
- Most parts are numbered and can be identified by a stamp or removable label. Alternatively, the components can be identified by lengths detailed in the packing list (see diagram opposite).
- The 4' cold frame is used primarily as an example throughout this manual. The 6' components are referred to in each section and they are fitted in a similar manner to the 4'.

Guarantee



- Your new Simplicity cold frame is guaranteed for 10 years against faulty manufacture of the framework. This does not include glazing, moving parts, accidental damage or wind damage.





Please note that this is a brand new instruction manual. If you find any mistakes or you think anything needs improving then please email me at; james@thegreenhousepeople.co.uk or phone 01782 388811






Part num	REAR Section	Size (mm)	2 4	2 6
950		1240	1	
951		1860		1
952		1240	1	
953		1860		1
958		510	2	
959		510	1	2
576			6	8
579			6	8
300			2	





Part num	FRONT Section	Size (mm)	2 4	2 6
950		1240	1	
951		1860		1
954		1240	1	
955		1860		1
960		460	2	
961		460	1	2
576			6	8
579			6	8
300			2	



Part num	Section	Size (mm)	2 4	2 6
956		580	2	
576			4	
579			4	





Part num	Section	Size (mm)	2 4	2 6
957		574	2	
576			4	
579			4	






4

Part num	Section	Size (mm)	2 4	2 6
962		425	2	3
574			2	3
589	 M6x24mm		2	3
586			4	6





5

Part num		2 4 6	2 6
572		1 roll	







	Size (mm)	4'	6'
856	 458	6	8
857	 508	6	8
A	610 X 457	2	3
B	610 X 508	2	3
C	See below	2	




Part num	Section	Size (mm)	2 4	2 6
----------	---------	-----------	--------	--------


121		612	2	3
123		612	2	3
124		610	4	6
858		588	4	6
D	610 X 610 (see diag)		2	3
576			8	12
579			8	12
572				



4




5






8

SLIDE IN VENTS FROM END




6'






6'

4'



Part num		2 4	2 6
580		4	6



9



573 x 4



4'&6' Cold frame packing List



No	mm	4'	6'
121	612	2	3
123	612	2	3
124	610	4	6
950	1240	2	
951	1860		2
952	1240	1	
953	1860		1
954	1240	1	
955	1860		1
956	580	2	2
957	574	2	2
958	510	2	2
959	510	1	2
960	460	2	2
961	460	1	2
962	425	2	3
576	 M6x10mm	28	36
579	 M6	28	36
589	 M6x24mm	2	3
586		4	6
574		2	3
300		4	4
580		4	6
856	 458	6	8
857	 508	6	8
858	 588	4	6
572	 15000	1 roll	1 roll
573		4	4