




Renaissance Assembly Instructions



NOMINAL SIZE	A (mm)	B (mm)	C (mm)
6 x 6	1678	1678	2373
6 x 8		2300	2847
6 x 10		2920	3368
6 x 12		3540	3918

GB Thank you for purchasing your new Robinsons greenhouse. We recommend you familiarise yourself with the instructions and read all safety information before you commence assembly. This instruction manual is also available online at www.robinsonsgreenhouses.co.uk in our technical help section should you need to reprint it. Should you require any additional advice you can always call us on 01782 385409.

These instructions are divided into sections highlighted by a white number/letter on a black background at the bottom corner of most pages (see opposite page for details); **part lists**, **B**-base, **P**-preparation, **1**-ends, **2**-front/rear, **3**-staging, **4**-roof, **5**-door, **6**-vent, **7**-cresting, **8**-louvre, **9**-glazing, **10**-vent attachment, **11**-door attachment **12**-anchoring down. If you need to contact us for assistance please refer to the relevant section/s. Please note that smaller page numbers are also present bottom middle and these should not be confused with section numbers.

Safety Warning

- Glass and aluminium can potentially cause injury. Please ensure you wear protective goggles, gloves, headgear and suitable footwear when assembling and glazing the building.
- Please remember that glass is fragile and should be handled with extreme care. Always clear up and dispose of any breakages immediately.
- Do not assemble the greenhouse in high winds.
- For safety reasons and ease of assembly, we recommend that this greenhouse is assembled by a minimum of two people.
- Please clear all lying snow from the greenhouse roof as it can cause the roof to buckle or collapse.

Site Preparation

- When selecting a site for your greenhouse, it is vital that you choose as flat and level an area as possible.
- A concrete or slabbed base will provide the most solid foundation for your greenhouse.
- **IMPORTANT:** Do **not** fix your building down until the building is fully assembled, including glazing.
- Avoid placing your greenhouse under trees or in other vulnerable locations.
- To minimise the risk of wind damage, try to select as sheltered a site as possible, e.g. beside a hedgerow or garden fence.

Additional Considerations

- Please bear in mind that assembling your greenhouse can be time consuming. You may need to spread the construction over two or more days. We recommend that you avoid leaving the building partially glazed. If you ever have to leave your greenhouse half assembled and not anchored down, weigh it down with slabs or bags of sand to stop the wind moving it.
- You will find it helpful to prepare a large, clean and clear area in which to work in. A garage floor or flat lawn area is ideal.
- If you have arranged for someone to install your greenhouse for you, please check that all components are included. The components can be identified by their distinctive profiles, lengths and quantities detailed in the parts list (see next page). You may find that you have a few additional door related parts which are not mentioned in this manual, they are **redundant** on this building.
- Anchoring down your greenhouse should be the final stage of construction (including glazing).
- Once installed your greenhouse requires little maintenance, but to maintain the smooth running of your door(s) WD40 or similar can be applied to the door wheels and lower door guides.

Guarantee

- Your new Robinsons greenhouse is guaranteed for 10 years against faulty manufacture of the frame-work. This does not include glazing, moving parts, accidental damage or wind damage.

UPDATE: Robinsons plastic / aluminium cover strips -

On a Robinsons building the glazing capping is in two parts. The lower plastic capping screws into the glazing bars pressing the glass down onto its rubber beading. The upper plastic / aluminium covers then need to be applied to cover the heads of the self-tapping screws. If you are struggling to press on the cover strips then we recommend the use of a rubber mallet or perhaps a wooden block and hammer, a short sharp tap onto the cover at one end is all that is needed to stretch the cover around the lower capping protrusions locking it into place. You can then either continue to use the mallet along the length of the cover or continue just using the palm of your hand. Once in the building and the edges are protected Robinsons 4mm thick toughened safety glass is very strong and can cope with the vibrations caused by hitting the covers though we would not recommend that you hit the glass directly. Some of the aluminium cover caps have a hole in them at one end which is sometimes used to hang the parts for powder coating. You can if you wish use the hole to stop the covers from sliding in the roof using a glazing screw, note you will have to use a countersunk screw under the vents to avoid interference with the vent bottom.



KEY SYMBOL	KEY DESCRIPTION
	EXTERNAL VIEW
	INTERNAL VIEW
	THINK
	THIS SECTION RELATES TO ANOTHER (e.g. 1 to 5)
	CORRECT
	DO NOT FIX DOWN!
	TWIST TO LOCK
	TIGHTEN
	PUSH AND HOLD
	CUT TO LENGTH

SECTION No	TITLE	ASSEMBLY SYNOPSIS: IMPORTANT INFORMATION / CONSIDERATIONS
B P 1 2 3 4 5 6a 6b 7 8 9 10 11 12	PARTS LIST	Identify and separate all like for like components prior to assembly. The 'parts list' also separates parts into the various sections 1 - 12 shown below. Parts can also be identified by their profile pictures and stated lengths etc..
	BASE	Base dimensions and recommendations. Ensure that your base is level as this will make assembly of the building, especially the glazing of the roof much more straight forward.
	PREPARATION	Tools required. <u>IMPORTANT</u> : Use WD40 or similar in the glazing bar channels and insert the black glazing rubber prior to frame assembly.
	OCTAGONAL ENDS	The ends of the building are almost identical on all length models. <u>IMPORTANT</u> : notice however that on the 6x6 version 2 x special handed cills are utilised at the door end.
	FRONT / REAR	Please make sure that the gutter containing the 36mm downpipe hole goes to the rear of the building else your downpipe it will interfere with the door.
	STAGING	Fitting the staging will add rigidity to the structure and help square the structure ready for roof construction. You can choose which height you would like for staging / shelf. Use a tape measure and spirit level to mark the heights of the 'D174' brackets.
	ROOF	Start with the middle section of the roof and then do the roof bars above the octagonal ends after. You may wish to employ another person to assist at this stage.
	DOOR/S	Please note that the 6x6, 6x8&10, 6x12 buildings all have different door/s, details are shown over 6 pages, refer to your relevant pages.
	VENT	Skip this section if you have the 6x6 model. Once the vent is glazed add silicone to the vent sides and top. Stand the vent/s on their hinge (vent top) and then leave the silicone to set.
	VENT SLAM	Skip this section if you have the 6x6 model. The slam bar 'D1009' can be moved up and down between the roof glazing bars so that it can be butted down onto the pane of glass beneath, the autovent will be attached to it later on (10).
	CRESTING / GUTTER JOINTS	It is a good idea to apply the cresting (not on 6x6) at this stage as the glass will inhibit your movement later on. The cresting is siliconed into place. While the silicone is open it is a good idea to add and silicone the gutter joints at the same time. The cresting interlocks together like a jigsaw. The finials however always have a male tab, one of these tabs will need to be sawn off to allow the cresting to abut it seamlessly.
	LOUVRE	Two louvres are supplied with each model and they are best fitted in the centre of the octagonal ends. They attach to the building during the glazing process '8' like a piece of glass with a black separator above and below them.
	GLAZING	Layout the bar cappings and covers around the building like a sundial checking that all is present and correct. You can also place the roof cappings in the gutters so they are closer to hand. The glass in the sides has to bevel on the black separator strip which is on top of the 305mm high glass base panels. This bevelling action allows the glass to tuck underneath the gutter canopy. Use the capping and the self tapping screws to then hold the glass in place. The covers then enclose the screw heads giving a neat finish. A top tip is to not attach the door post capping (D814 / D836) until you have fitted the door runner and threshold (11) to give you more room to manoeuvre.
	VENT ATTACHMENT	Take the assembled vent and manoeuvre through the vent aperture. Slide the vent hinge 'D1013' into the end of the ridge allowing the vent the pivot open and closed. Vent stops go either side of the vent to stop any lateral movement. Attachment of the autovents.
	DOOR ATTACHMENT	There are three different types of door track depending on which model you have purchased. Please make sure you refer to the one relevant to you.
	ANCHORING DOWN + FINISHING TOUCHES	Now that the greenhouse is finished and the doors and vents are operating without interference then you need to anchor the building down using 2" rawl plugs and screws. Use a 7mm masonry bit in a hammer drill to create the holes.
		The downpipe and its fittings can be attached and silicone sealed through the appropriate gutter, Ref. section 2.

Section Ref	Part No.	Section	Size (mm)	6 6	6 8	6 10	6 12
-------------	----------	---------	-----------	-----	-----	------	------

1	D1005 D1042 (LH) D1043 (RH)		700	4 1 1	6 0 0		
	D1000		726		6		
	D1002		1930		8		
	D1022		N/A		8		
	RUBBER		1000 (1m)		32		
	D174		N/A		4		

2	D1005		700	2			
	D1006		1321		2		
	D1035		1941			2	
	D1036		2561				2
	D508		1930	0	2	4	5
	D1000		726	1			
	D1041 (+hole)		726	1			
	D1001 (+hole)		1347		1		
	D1028		1347		1		
	D1029		1966			1	
	D1030 (+hole)		1966			1	
	D1033 (+hole)		2586				1
	D1034		2586				1
	RUBBER		1000 (1m)	0	8	16	20
	D174		N/A	4	6	8	9

3	D174		N/A	16	17	18	19
	D275		10	1 = SYBOLM6X11CROP 1 bag of 25			
	D243		N/A	1 bag of 25			
	D2042		600	6	7	8	9
	D2014		385	4			

Renaissance


Section Ref	Part No.	Section	Size (mm)	6 6	6 8	6 10	6 12
-------------	----------	---------	-----------	-----	-----	------	------

4	N/A		N/A	0			
	D1004		650		1		
	D1031		1270			1	
	D1032		1890				1
	D1007		955	0	4	8	8
	D1003		960		8		
	D077		N/A	1		0	
	D1021		N/A	0		2	
	D1037		16	0		2	
	F1001		35	0		4 (hex head)	
	F5006		M6	0		4	
	RUBBER		1000 (1m)	16	24	32	32

5	D090 + D302 lock = D301		1824	1			
	D092 + D156 strike = D303		1824	1	N/A		1
	D093		1824	1	N/A		1
	D094		1824	1			
	D059+ D217 wheel = D060		305	2	0	0	0
	D096 + D217 wheel = D307		611	0	1	1	2
	D061		305	2	0	0	0
	D095		611	0	1	1	2
	D062		305	2	0	0	0
	D097		611	0	1	1	2

Section Ref	Part No.	Section	Size (mm)	6 6	6 8	6 10	6 12
-------------	----------	---------	-----------	-----	-----	------	------

5	D232		905	4	2	4
	D233		797	4	2	4
	P053		N/A	2	1	2
	D225		610	1 cut	.1	2
	D840B		4000	1		
	D263 Pack of 7		N/A	14	7	14

6	D1013		580	0	1	2	2
	D1011		453	0	1	2	2
	D1012		453	0	1	2	2
	D1010		534	0	1	2	2
	D1009 PLUS FLUFF		528	0	1	2	2
	D114		N/A	0	2	4	4
	D220 PLUS FS6060 SCREW		N/A	0	2	4	4
	D205R		N/A	0	2	4	4




7	D1024		N/A	8			
	ROCRE ALU G/W		N/A	0	2 (1.5)	4 (3.5)	6 (5.5)
	ROFIN ALU G/W + DV281 spacer		N/A	0	2		
			150	0	1		

Section Ref	Part No.	Section	Size (mm)	6 6	6 8	6 10	6 12
-------------	----------	---------	-----------	-----	-----	------	------

9

1/2/3	D541		1915	14	16	18	19	
	4a	D1019		965	0	4	8	8
	2	D814		1883	2			
	4b	D1026		970	8			
	1/2/3	D544		1915	14	16	18	19
	2	D836		1883	2			
	4a	D1020		965	0	4	8	8
	4b	D1027		970	8			
	D076			N/A	1	0		
	D1023				0	2		
FS6018			19	4				

11

D514		590	1	N/A	
D512		1210	N/A		1
D864		590	N/A	1	N/A
D860		1240	1		N/A
D861		2450	N/A		1
D087		587	1		N/A
D088		1207	N/A		1
D081		1270	1	0	0
D083		1270	0	1	0
D085		2510	0	0	1
D082		1270	1	0	0
D084		1270	0	1	0
D086		2510	0	0	1
D163		90	2		
D150		N/A	1	N/A	1
D204L& R /B		1 + 1			
D845		2			
D312		2			

FS6505HEX 12mm		10	48	50	60	61
FS6506HEX 16mm		15	38	38	40	44
FS6504M6		M6	86	88	100	105
FS6016		10	80	110	130	140
RUBBER TOTAL		1000 (1m)	48	64	80	84

RENAISSANCE EXTERNAL BASE DIMENSIONS (mm)

Model sizes listed are **nominal**,
use 'mm' measurements.

MODEL	A (mm) WIDTH	B (mm) LENGTH	C (mm) DIAGONAL
6 x 6	1678	1678	2373
6 x 8		2300	2847
6 x 10		2920	3368
6 x 12		3540	3918

THE DIMENSIONS BELOW ARE THE EXACT EXTERNAL BASE DIMENSIONS FOR THE ROBINSONS RANGE.




We cannot emphasize how important it is to have a proper base for your Robinsons Greenhouse to be erected upon.

It is essential that the **BASE IS FLAT, LEVEL AND SQUARE AS WELL AS BEING SUBSTANTIAL** enough to take the weight of the greenhouse including its 4mm glass.

Give yourself enough room around your base to allow for fitting the glass and any on-going maintenance / cleaning. A slab base which is larger than the greenhouse is the ideal solution and is our preferred foundation.

A brick perimeter base is equally suitable providing there is a concrete foundation beneath it. We suggest using a solid brick with no frogs or holes (quality stock bricks or semi-engineering bricks).

IMPORTANT: Do not anchor your greenhouse down until it is fully assembled including glazing unless you are 100% sure your base is square and level. If not your glass will not fit properly.



B





Robinsons have now upgraded the original square headed alloy bolts to stainless steel **Hexagonal** headed bolts. The frame is assembled by feeding these bolts, either 12mm or 16mm in length (previously 10mm and 15mm) into the slots on glazing bars and then locating those bolts through holes in purlings and cills, etc... The 12mm bolts tend to be used to join two parts together and the 16mm bolts tend to be used to join two or more parts or where an extrusion is thicker.

Twist in (rectangular) crop headed bolts are also used towards the end of construction to attach components to the frame retrospectively when the glazing bar slots are no longer exposed at the ends.


e.g.




If an image in the manual shows a square headed bolt please interpret it as the new HEX headed replacement.

	ORIGINAL SQUARE HEAD		NEW HEX HEAD
10mm		12mm	
15mm		16mm	

				6	6	6	6
				X	X	X	X
				6	8	10	12
Part No		mm	Quantity				
D1005		700	4	6			
D1042 (LH)		700	1	0			
D1043 (RH)		700	1	0			
D1000		726	6				
D1002		1930	8				


Part No		mm	Quantity
D1022		N/A	8
RUBBER		1000 (1m)	16
D174		N/A	4
M6X12		12	24
M6X16		16	12
M6NUT		N/A	36





1

2







6x6		
		
Part No	mm	Quantity
D174	N/A	4
D1000	726	1
D1005	700	2
D1041	726	1
M6X12	12	8
M6X16	16	4
M6NUT	N/A	12

6x8		
		
Part No	mm	Quantity
D174	N/A	6
D508	1930	2
D1001	1347	1
D1006	1321	2
D1028	1347	1
RUBBER	1000	8
M6X12	12	10
M6X16	16	6
M6NUT	N/A	16


6x10		
		
Part No	mm	Quantity
D174	N/A	8
D508	1930	4
D1029	1966	1
D1030	1966	1
D1035	1941	2
RUBBER	1000	16
M6X12	12	12
M6X16	16	8
M6NUT	N/A	20

6x12		
		
Part No	mm	Quantity
D174	N/A	9
D508	1930	5
D1033	2586	1
D1034	2586	1
D1036	2561	2
RUBBER	1000	20
M6X12	12	13
M6X16	16	9
M6NUT	N/A	22







2


			6 x 6	6 x 8	6 x 10	6 x 12
Part No		mm	Quantity			
D174		N/A	16	17	18	19
SC105		10	1 bag of 25			
D256 D243		19 19	= 1 bag of 5 = 1 bag of 25			
D2042		600	6	7	8	9
D2014		385	4			



		6 x 6				6 x 8				6 x 10				6 x 12			
Part No	WOODEN DESCRIPTION	Quantity															
D2160T	OCT SHELF	2															
D2161T	OCT STAGE	2															
D2169T	6' RECT STAGE	1	0	0	0												
D2163T	8' RECT STAGE	0	1	0	0												
D2165T	10' RECT STAGE	0	0	1	0												
D2167T	12' RECT STAGE	0	0	0	1												
D2168T	OPTIONAL 6' SHELF	1	0	0	0												
D2162T	OPTIONAL 8' SHELF	0	1	0	0												
D2164T	OPTIONAL 10' SHELF	0	0	1	0												
D2166T	OPTIONAL 12' SHELF	0	0	0	1												






3



6x6
 Turn page for other Sizes (6x8, etc..)




Part No	mm	Quantity
D1003	960	8
D077	N/A	1
RUBBER	1000	16
M6X16	16	16
M6NUT	N/A	16




4


(6x6only)
pto for
other sizes






Part No	mm	Quan.
D1003	960	8
D1004	650	1
D1007	955	4
D1021	N/A	2
D1037	16	2
FS6006	35	4
F5006	M6	4
RUBBER	1000	24
M6X12	12	8
M6X16	16	16
M6NUT	N/A	24



Part No	mm	Quan.
D1003	960	8
D1031	1270	1
D1007	955	8
D1021	N/A	2
D1037	16	2
FS6006	35	4
F5006	M6	4
RUBBER	1000	32
M6X12	12	16
M6X16	16	16
M6NUT	N/A	32



Part No	mm	Quan.
D1003	960	8
D1032	1890	1
D1007	955	8
D1021	N/A	2
D1037	16	2
FS6006	35	4
F5006	M6	4
RUBBER	1000	32
M6X12	12	16
M6X16	16	16
M6NUT	N/A	32



(6x8)







(6x10)

(6x12)

4




1





(6x8)
(6x10)
(6x12)
4







6x6




Part No		mm	Q
D094		1824	1
D090 + D347 lock = D301		1824	1
D092 + D156 strike = D303		1824	1
D093		1824	1
D059+D217 wheel = D060		305	2
D061		305	2
D062		305	2

Part No		mm	Q
D232		905	4
D233		797	4
P053		N/A	2
D225		610 (cut 2 x 305)	1
D840B		4000	1
D263 PACK x 2			14
D261 PACK			24















Part No		mm	Q
D090 + D347 lock = D301		1824	1
D094		1824	1
D096 + D217 wheel = D307		611	1
D095		611	1
D097		611	1


Part No		mm	Q
D232		905	2
D233		797	2
P053		N/A	1
D225		610	1
D840B		4000	1
D263 PACK			7
			7
D260 PACK			12







5 (6x8)
+
(6x10)







6x12




Part No		mm	Q
D094		1824	1
D090 + D347 lock = D301		1824	1
D092 + D156 strike = D303		1824	1
D093		1824	1
D096 + D217 wheel = D307		611	2
D095		611	2
D097		611	2

Part No		mm	Q
D232		905	4
D233		797	4
P053		N/A	2
D225		610	2
D840B		4000	1
D263 PACK x 2			14
D261 PACK			24













Part No		mm	Quantity
D1013		580	1
D1011		453	1
D1012		453	1
D1010		534	1

Part No		mm	Quantity
D220 PLUS FS6060 SCREW		N/A	2
D205R		N/A	2
BOLM6X12		12	4
NUT M6		M6	4
8 X 12 S/T FS6017		10	2
8 x 19 S/T FS6018		19	2



6a (6x8)
(6x10)
(6x12)




6a (6x8)
(6x10)
(6x12)

1 vent
slam bar = {




Part No		mm	Quantity
BOLM6X12		12	4
BOLM6 X11CROP		10	2
NUT M6		N/A	4

Part No		mm	Quantity
D1009 PLUS FLUFF		528	1
D114		N/A	2

6










6b (6x8)
6b (6x10)
6b (6x12)








6b (6x8)
(6x10)
(6x12)


PART No		6	6	6	6
		X	X	X	X
		6	8	10	12
D1024		8			
ROCRE ALU W/G		0	2	3.5 (4)	5
ROFIN ALU W/G		0	2		






- End finials need to be pinched onto the ridge using 'DV282' grub screws.
- A half cresting piece will need to be cut along with some spacer bar 'DV281' cut into two equal sections (see below right).
- Each finial and cresting piece needs to be siliconed 'D119' into place.










Part No		mm	Quantity
D168L		552	1
D168R (handle)		552	1
D165		612	2
D166		552	2
FS6013		12	4





PART No	Size (mm)	6 X 6		6 X 8		6 X 10		6 X 12	
		5	7	9	10	11	12	13	14
D519	S	610 X 1628	5	7	9	10			
D1254	B	610 X 305	7	9	11	12			
D521	M	610 X 1016	2						
D729TG	L	100 X 525	12						
D1016	U	550 X 550	0	2	2	2			
D1017	V	550 X 450	0	2	2	2			
D1040	W	300 X 980	0	0	4	0			
D1039	X	610 X 980	0	0	0	4			
D101 / ROSEPS	H	610	9	11	13	14			






DOOR PANES FROM SECTION 5		6 X 6	6 X 8	6 X 10	6 X 12
D909	247 X 812	2	0	0	0
D910	247 X 922	2	0	0	0
D911	555 X 812	0	1	1	2
D912	555 X 922	0	1	1	2


RENAISSANCE TOUGHENED GLASS




PART No	Section	Size (mm)
D541		1915
D1019		965
D814		1883
D1026		970
D544		1915
D836		1883
D1020		965
D1027		970






(6x6)






(6x8)
(6x10)
(6x12)



9











10 (6x8)
(6x10)
(6x12)






PART No		6 X 6	6 X 8	6 X 10	6 X 12
D514		1	N/A		
D512		N/A			1
D864		N/A	1	N/A	

PART No		6 X 6	6 X 8	6 X 10	6 X 12
D081 D083 D085		1	1	1	1
D082 D084 D086		1	1	1	1








PART No		6 X 6	6 X 8	6 X 10	6 X 12
D150		1	N/A		1
D522 (48mm)		N/A			1





PART No		6 X 6	6 X 8	6 X 10	6 X 12
D163		2			
D845		2			
D860		1			N/A
D861		N/A			1
D087		1			N/A
D088		N/A			1




PART No		6 X 6	6 X 8	6 X 10	6 X 12
D312			2		
D204L /B			1		
D204R /B			1		



PART No		6 X 6	6 X 8	6 X 10	6 X 12
D842		0	1	1	0
D112		0	0	1	0
M6 crop		0	2	3	0



11



12

Please be aware that this is a multi-national manual, if you spot any errors or have any constructive comments regarding the manual please email james.spooner@greenhousepeople.co.uk and I will make the necessary amendments. Whilst the information contained in this booklet is accurate at the time of publication, changes in the course of Robinsons policy of improvement through development and design might not be indicated. We point out this fact to avoid any infringements of the Trade Descriptions Act and also to advise that Robinsons Greenhouses reserve the right to change specifications and materials without prior notice.

In addition any photographs of completed buildings would be most appreciated to add to our portfolio.

THIS GREENHOUSE BOX WAS PACKED BY:

DATE: _____



www.robinsonsgreenhouses.co.uk

To contact Robinsons Customer Services email us at sales@robinsonsgreenhouses.co.uk or call us on 01782 385 409.

Our address is Robinsons Greenhouses, Unit 19 Blythe Park, Cresswell, Stoke-on-Trent, Staffordshire, ST11 9RD